


## How to connect 6 volt Batteries in series

For any further information please call 1300 0 SOLAR or email on [info@dynamicssolutions.com.au](mailto:info@dynamicssolutions.com.au)



This diagram is to be used as an example only



# Jamie's 12 Volt Solar Shop

8 Allen Street Moffat Beach QLD 4551

PH: 07 5492 5071

1300 0 SOLAR/ 76527

FAX: 07 5437 0649

[info@dynamicssolutions.com.au](mailto:info@dynamicssolutions.com.au)

[www.dynamicssolutions.com.au](http://www.dynamicssolutions.com.au)