


Battery Positive 'Main' (to load e.g. charger or inverter)



## Link Lite Wiring

- ♦ Make sure the batteries you install are always in good health, preferably fully charged



- ♦ Ensure no other negative wire is connected to house battery.



## Jamie's 12 Volt Solar Shop

8 Allen Street Moffat Beach QLD 4551

PH: 07 5492 5071

1300 0 SOLAR/ 76527

FAX: 07 5437 0649

info@dynamicsolarsolutions.com.au

www.dynamicsolarsolutions.com.au